

# QuickScan-i-QD21x0 R96-9252

## Restore Custom Defaults

<FNC3>\$P,HA00,P<CR>



\$P,HA00,P

## Enter Configuration

<FNC3>\$P<CR>



\$P

## Interface Selection: USB-KBD

<FNC3>\$HA35<CR>



\$HA35

## Character Conversion: T [00 NUL] P [00 NUL] [20 SPACE] [00 NUL]

<FNC3>\$CLFCH540050002000FFFF<CR>



\$CLFCH540050002000FFFF

## I 2 of 5 Enable/Disable: Enable

<FNC3>\$CI2EN01<CR>



\$CI2EN01

**Follett 2 of 5 Enable/Disable: Enable**

<FNC3>\$CF2EN01<CR>



\$CF2EN01

**I 2 of 5 Check Character Transmission: Disable**

<FNC3>\$CI2CT00<CR>



\$CI2CT00

**Codabar Enable/Disable: Enable**

<FNC3>\$CCBEN01<CR>



\$CCBEN01

**Codabar Check Character Transmission: Disable**

<FNC3>\$CCBCT00<CR>



\$CCBCT00

**Code 4 Enable/Disable: Enable**

<FNC3>\$CCREN01<CR>



\$CCREN01

**Code 5 Enable/Disable: Enable**

<FNC3>\$CC5EN01<CR>



\$CC5EN01

**ule line 1: \$U00000008554C453200060A0A**

<FNC3>\$U00000008554C453200060A0A<CR>



\$U00000008554C453200060A0A

**Exit Configuration**

<FNC3>\$P<CR>



\$P